





### CONTENTS OF THE EXUS LA A EXIT BAR PACKAGE

Position	pz	Description	Position	pz	Description
1, 2	01	Exus LA mechanism assembly	15	02	Washer
3, 4, 5	01	Exus LA casing package with plugs	16	02	Toothed washer
6	01	EXUS lever-arm package	17	02	Self-tapping screws with cylindrical heads, 5.5x13 mm
7	02	M5x16 mm Phillips-head screws	18	01	Companion link-arm (for Multipurpose doors by request only - idem pos. 15, 16, 17)
9	01	Hex wrench S2	21	01	Proget bushing (Counterstrike) and 3 fasteners
11	01	Aluminum bar	21	01	Univer bushing (Counterstrike) and 2 fasteners
12	01	Square pivot 9x9x52 mm	21	01	Rever bushing (Counterstrike) and 1 fastener
13	04	Toothed washer	28	01	Adhesive pictogram (green arrow)
14	04	Self-tapping screws with cylindrical heads, 4.8x16mm	-	01	A034 hole-drilling template
			-	01	EXUS LA A Kit exit bar installation instructions



Please note that article 4 of the MD of 03 November 2004 obliges the Installer to write up, sign and provide the owner of the activity with a declaration of proper installation that makes explicit reference to the instructions supplied by the exit device manufacturer.

N.B. The door is provided with the safety lock (20), rods (8, 10), upper relatch device (22) and upper counterstrike (23) already installed.

### TOOLS REQUIRED

Medium-sized phillips-head screwdriver or electric screwdriver, electric drill with Ø 3 mm, Ø 4,2 mm and Ø 20 mm drill bits for steel, hack-saw for aluminum.

## IMPORTANT

- Installation should be carried out by qualified personnel only and in strict conformity with the instructions supplied below.
- Proper installation incorporates all supplied components, including the toothed washers.



- No variations are allowed, and only components indicated in the package contents may be used.
- Given its function, the EXUS LA A panic exit device should only be mounted on the push side of the passive leaf and always be combined with the panic exit device of the active leaf.
- Prior to assembly, check all the contents of the package.
- Check whether the panic safety lock on the passive leaf was applied in the right direction.
- The only installation configurations that may be used are described in the outline on pages 2-4.
- Ensure that the main leaf is also equipped with the EXUS LA panic exit device.

## INSTALLATION

- If not already installed, apply the floor-mounted bushing (21) by attaching it with the appropriate screws and fasteners according to the door installation instructions.

- Proceed with assembly of the exit bar. If no hole is present for passage of the follower, drill the hole in the metal panel from the push side of the door using the Ø 20 mm drill bit, positioning it as indicated in the figure (24).

- Level the template and drill the holes (19) using the Ø 3 mm drill bit, drilling the internal reinforcement as well.



- Insert the follower (12) on the control mechanism (1) until it just touches the spring, then block it with the threaded pin and tighten using the S2 hex wrench (9).

- Apply the mechanism (1) by centering the follower (12) carefully over the hole in the safety lock (20), supporting it against the surface of the door and attaching it with self-tapping screws 4.8x16 mm (14) and their toothed washers (13).

- Fasten the exit bar mechanism (2) at the hinge end using self-tapping screws 4.8x16mm (14) and their toothed washers (13).

- Apply the casing (3) to the mechanism (1) after removing the externally-facing plug (5). To do this, insert a finger inside the casing and push the plug out, being careful not to remove the plastic insert. Repeat the same operation with the casing (4) and the mechanism (2). Do not fasten the pins, so as to leave some play in the two casings.

- Apply the link arms (6) and block them with the designated screws (7) using a Philips-head screwdriver.

- Make a precise "L" measurement and cut the aluminum bar (11), adding 20 mm; remove the burs from the bar; remove one link arm, attach the bar and re-fasten the assembly.

- Finish fastening the casings (3) and (4), using the wrench (9) to screw in the pins without using excess force, then apply the plugs (5).

- Apply the companion link arm (18) as shown in the drawing, fastening it with two self-tapping screws 5.5x13 mm (17) and their washers (15 and 16).

- For PROGET doors, the holes for the link arm are already provided, simply regulate the rubber spacer (27) so that it rests properly on the leaf.

- For UNIVER and REVER doors, alternatively, drill 2 holes (26) with the Ø 4.2 mm drill bit 60 mm away from the upper rabbet of the leaf and 40 mm apart. For UNIVER doors, the first hole should be made 40 mm from the lateral edge of the centerpost, while for Rever doors the distance is 33 mm.

- For UNIVER and REVER doors, unscrew the rubber spacer (27) and keep the nut (25), which will serve as a spacer for attaching the link arm through the third slot.

- Adjust the position of the companion link arm so that it acts on the exit bar of the passive leaf. The active leaf is pushed just enough to ensure the correct closing sequence for the two leaves (active leaf held in waiting position by the closing regulator).



- Activate the EXUS LA A exit device at any point along the horizontal bar and check for the complete exit of the counter-latchbolt and full retraction of the relatch device (22) and lower rod (8). Test the system with the doors open and closed. For fire doors, verify that the self-closing sequence of the two leaves functions properly.

- Apply the pictogram (28) with the green arrow on the internal surface of the door, just above the activation bar.

- Lastly, use a dynamometer to measure the force required on the horizontal bar of the EXUS LA A bar to free the passive leaf from the latch bolt of the latch mechanism and the upper and lower latches. Record this force measurement in the present document.

## USE

- Ensure that the door always opens easily.
- Avoid unnecessary strains on or handling of the exit bar.
- Protect the exit bar from external atmospheric agents.
- Ensure that nothing obstructs free movement of the exit bar.
- Do not paint the safety lock or the upper and lower latch devices.
- Use the bar properly, do not pull it in the wrong direction.



- Make sure that any damaged or malfunctioning parts are replaced immediately.

## MAINTENANCE

To ensure that door usage conforms with regulations, the following maintenance checks should be carried out at least once a month:

- Confirm that all of the installed components correspond with those listed in the present instructions, and that no latching devices other than those originally installed have been added to the door.

- Inspect and activate the panic exit device to verify that all of its components are in satisfactory operational condition.

- Use a dynamometer to confirm that the release force shows no significant differences from the forces recorded at the time of installation.



- Check whether all screws are fully tightened, tightening any that may have loosened.

- Activate the EXUS LA A panic exit device by pushing it all the way down at any point along the horizontal bar in order to verify that the counter-latchbolt of the latch mechanism comes completely out, and that the upper relatch device (22) and the lower rod (8) retract all the way. Test the system with the doors open and closed.

- Check whether the counter-latchbolt fully re-inserts upon release of the exit bar, and that the upper device and lower rod come completely out.

- For fire doors, open the two leaves by activating the exit bar of the secondary leaf, then confirm the correct closing sequence of the two doors.

- Check the aluminum bar and replace it if any damage or deformities are detected.



- Ensure that the upper and floor-mounted counterstrikes are not blocked; if so, remove the obstruction.

- The product requires no special maintenance. Grease spray should be used to lubricate the upper relatch device, the lower rod guide, internal workings of the safety lock and the exit bar on a regular basis - the latter has a hole on the underside of its casing for this purpose.

- For normal cleaning, use cleaners designated for chromated surfaces.



**Any adjustments that become necessary must be carried out by qualified personnel using original NINZ replacement parts.**



**The owner of the activity is responsible for keeping the declaration of correct installation on file, conducting proper exit bar maintenance in accordance with all of the manufacturer's maintenance guidelines, keeping maintenance and check-up records and preserving the present document.**

REPLACEMENT PARTS (see expanded drawing, pages 2-4)

Position	Code	Description
1, 2, 3, 4, 5, 6, 7, 28	3102058	Exus LA Base
1, 2	3105113	Twist/Exus mechanism assembly
3, 4, 5	3105161	Exus LA casing package with plugs
6	3105139	Exus LA lever-arm package
7	3105093	Exus LA bag
11	4204009	Anodized or painted aluminum bar package
9, 12, 13, 14, 21	4211101.041	Twist/Exus Proget package A
9, 12, 13, 14, 21	4211101.042	Twist/Exus Univer package A
9, 12, 13, 14, 21	4211101.043	Twist/Exus Rever package A
20	3201001.024	AP020P Panic safety lock for Proget and Univer fire doors
20	3201001.008	AP020U Panic safety lock for Rever and Univer multipurpose doors
22	3105080	Proget relatch device
22	3105024	Univer and Rever relatch device
10	3305015	Proget, Univer and Rever upper rod
8	3305016	Proget lower rod
8	3305002	Univer and Rever lower rod
23	2401046	Proget upper counterstrike
23	2401044	Univer and Rever upper counterstrike
15, 16, 17, 18	3305001	Companion link arm with washers and screws



ANY REPLACEMENTS MUST USE ORIGINAL NINZ REPLACEMENT PARTS FROM ITS FULL CERTIFIED SYSTEM!

Certified EXUS LA A components

Panic exit device series:

"EXUS LA A"

- Panic safety lock devices: art. AP020P, AP020U
- Upper device: art. 3105080, 3105024
- Rod counterstrike: art. 2401036, 2401046, 2401044
- Floor-mounted bushing: art. 2401001, 2401007, 3105091
- Vertical rods: art. 3305015, 3305016, 3305002
- Safety lock controls: art. A

PROPER DISASSEMBLY

When some or all of the bar needs to be replaced, the general approach is to reverse the order of the original installation instructions. Replacement of rods and/or the upper device first requires that the safety lock be disassembled. Replacement of the safety lock first requires that all parts of the exit bar in the latch mechanism zone be disassembled. The safety lock (20) can be disassembled by unscrewing the 2 frontal screws, first detach the heat-expanding seal that is glued over the fastener screws (only for fire doors).



The operation should be carried out with great care, being sure not to ruin or displace any of the components inside the safety lock housing, and re-attaching the rods with great care!

MAINTENANCE RECORD

Date	Description of intervention	Release force checked	Operator
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____



These instructions should be given to the owner of the activity, who shall preserve them as a record of the maintenance operations carried out on the panic exit device.