


CONTENTS OF THE HOT-CIL EMERGENCY DEVICE KIT PACKAGE


position	pcs.	description	position	pcs.	description
1, 1a, 1b	01	Single mastered cylinder with thumbturn latch, three keys and fastening screw	10, 10a, 10b	01	Fix doorknob with black plastic cover plate, M5 threaded inserts and galvanized steel installation plate
2	01	Cover plate at handle-side	11	01	S2 hex key
3, 4	01	Handle with galvanized steel installation plate	12	01	Panic safe lock to push and pull (AP sp ti)
5	01	Ø10,3x60,6mm spacer	13	01	Proget strike box lock
6	02	Ø15,0x23,5mm spacer	15	01	Adhesive pictogram (green arrow)
7	01	Black cap hole Ø8,8mm	16	01	Square spindle 9x9x115mm
8	02	M5 toothed washer	-	01	Hot-Cil handle set Kit installation instructions
9	02	M5x50mm countersunk flat head screw			

 Please note that article 4 of the MD of 03 November 2004 obliges the installer to write up, sign and provide the owner of the activity with a declaration of proper installation that makes explicit reference to the instructions supplied by the exit device manufacturer.

TOOLS REQUIRED


Medium-sized Philips-head screwdriver or electric screwdriver, fine-toothed hack-saw.

IMPORTANT


- Installation should be carried out by qualified personnel only and in strict conformity with the instructions supplied.
- For a correct installation all supplied components must be used, including spacers and toothed washers.
-  - No variations are allowed, and only components indicated in the package contents may be used.
- Before proceeding with installation, check the package contents to ensure that no pieces are missing.
- Any different installation configuration from that illustrated on page 2/4 is not allowed.

INSTALLATION


- First disassemble any handles components that are already present.
- Unscrew the two frontal screws (14) and take away the existing lock.
- Install the new panic safe lock to pull (12) and fasten it with the same two frontal screws (14).
- Put the cam in vertical position and insert the cylinder (1) into the lock (12) with the thumbturn latch-side at the pull-side of the door; fix it provisionally with the screw (1b).
- Adjust the plastic spacers (5 and 6) to the thickness of the leaf so that they do not protrude more than 1mm from it.
- Insert the handle (3) into the hole of the respective installation plate (4) and turn it for 90 degrees.
- Apply the handle with installation plate (3 and 4) to the pull-side of the door after inserting the square spindle (16), screws (9), toothed washers (8) and spacer (6). Take care to center the square spindle into the lock (12), the screws into the respective holes and the installation plate over the cylinder.
- Insert the two spacers (5 and 6) over the threaded inserts (10b) which are inserted in the installation plate of the fix doorknob (10) and apply the last one to the push-side of the door.
- Center the square spindle, the cylinder and the screws, starting the screws by hand before fastening them with the screwdriver; take care to not deform the installation plate.
- Finish fastening the cylinder (1), insert the little cap hole (7) in the open hole of the panic safe lock (12).

-  - Use the Hot-Cil handle to ensure that the latch bolt (12a) of the lock opens easily and fully. Further check if the latch bolt opens and if the deadbolts are operating both by using the key. Test the door in both open and closed positions, and if necessary file down the plastic strike box (13).

- Insert the cover plate (2) over the handle (3), turn the cover plate (10a) of the fix doorknob (10) and clip on both coverplates at the respective installation plates.
- Insert the thumbturn latch (1a) over the spindle of the cylinder (1) and fix it with the S2 hex wrench (11).
- Apply the pictogram (15) with the green arrow on the internal surface of the door, just above the Hot-Cil handle.

-  - Lastly, use a dynamometer to measure the force required on the lever of the handle to free the lock. Record this force measurement in the present document.


USE

- Ensure that the door always opens easily.
- Avoid unnecessary strains on or handling of the handle and the fix doorknob.
- Protect the handle and the fix doorknob from external atmospheric agents.
- Ensure that nothing hinders the free movement of the lever of handle.
- Do not paint the lock.
- Use the handle and the fix doorknob properly, do not pull the lever of handle in the wrong direction.
- Do not leave the key in the lock.
-  - Make sure that any damaged or malfunctioning parts are replaced immediately.

MAINTENANCE


To ensure that door usage conforms with regulations, the following maintenance checks should be carried out at least once a month:

- Confirm that all of the installed components correspond with those listed in the present instructions and that no other latching devices than those originally installed have been added to the door.
- Inspect and activate the emergency device to verify that all of its components are in satisfactory operational condition.
- Use a dynamometer to confirm that the release force shows no significant differences from the forces recorded at the time of installation.

-  - Check whether all screws are fully tightened, tightening any that may have loosened.


- Check whether handle and key can be moved with minimal effort, and that the latch bolt of the lock retreats from the strike box without offering resistance. If the door has become difficult to open due to friction, the resistance can be reduced by filing the strike box down to the appropriate height.


- Ensure that the latch bolt exits completely when the handle is released.

-  - Check whether the inserts and strike boxes are blocked in any way and eliminate any obstructions.

- This product don't requires any special maintenance. Grease should be used to lubricate periodically the internal workings of lock and handle.

- For normal cleaning use mild detergents.

-  - Any adjustments that become necessary must be carried out by qualified personnel using original NINZ replacement parts.

-  - The owner of the activity is responsible for keeping the declaration of correct installation on file, conducting proper emergency device maintenance in accordance with all of the manufacturer's maintenance guidelines, keeping maintenance and check-up records and preserving the present document.

